

**Step 1**

Attach both sliders to the frame with 1x M8x12 bolt as shown.

Step 2

Bend the slider handle to the desired width*. Use the handle to move both the left and right slider backwards exposing the fastening holes in the front.

Step 3

In the backwards position, attach the left and right seat bracket as shown using a M8x16 bolt + M8 Locknut.

Step 4

Slide the slider to the front and repeat for the front-end of the seat brackets.

