



- Thrustmaster “Ferrari F1 wheel Integral T500” -
- “GAME STOCK CAR - PC” -
- Profile name: “GameStockCar\_Ferrari F1 T500\_01” -



**1) In the Control Panel, change the default Settings to these new settings:**



- **"Advanced Mode"** (for 29 available functions)
- Rotation Angle = 270°
- Pedals = Separate




- Overall Strength of all forces = 45%
- Constant = 100%
- Periodic = 70%
- Spring = 100%
- Damper = 20%
- Auto-Center Settings = by the game

**2) Unzip the « GameStockCar Ferrari F1 T500\_01.rar » file in "GameStockCar/USERDATA/Controller"**



**3) In OPTIONS/CONTROLS/PRESETS, select « Ferrari F1 T500\_GSC01 », then click on « LOAD »**




***You are now ready to race!***

# Thrustmaster "Ferrari F1 wheel Integral T500"

## "GameStockCar" – Profile

(29 programmable functions)



1 = Shift Down
2 = Shift Up
3 = Speed Limiter
4 = Request Pit
5 = Driving Cameras
6 = Brake Bias (F)
7 = LCD Mode
8 = Reset FFB
9 = Look Behind
10 = Temporary Boost
11 = Launch Control
12 = Brake Bias (R)
13 = Pause
14 = LCD Up
15 = LCD Down
16 = LCD Decrease
17 = LCD Increase
18 = Adjust Seat Fore
19 = Adjust Seat Aft
20 = Adjust Seat Down
21 = Adjust Seat Up
22 = Vote No
23 = Vote Yes
24 = Toggle AI Control
25 = Restart Race
Pov Up = Look Up
Pov Down = Look Down
Pov Left = Look Left
Pov Right = Look Right